

1 Trim, reinforce and re-hem any frayed edges to extend the life of your promotional flag.

2 Flags can be machine washed at 30° C with everyday detergents. Always allow your flag to completely dry before storing.

3 Consider where you position your flag as air pollution will cause the white areas to become grey and UV can, over time, cause deterioration and fading to the fabric.

4 Dismantle your flag during adverse weather conditions, including strong winds above 18mph. Heavy rain combined with high winds can increase the weight of the flag and put extra strain on the pole

5 Ensure that your flag doesn't catch or snag on any surrounding objects. Do not place too close together. To avoid this allow room between flag & surrounding objects

