

1.



The Display Boards are supplied with a black fabric carry bag for easy transportation

2.



Remove top and bottom panels from the fabric carrying bag

3.



Position the boards until a stable shape has been achieved. Place the top panel onto the bottom panel.

4.



Slot the panels together by locking the top panel into the bottom panel

5.



If you have ordered a 7 Panel Kit add the steel shelf.

6.




Slide the fixing channel over each end frame, to secure into place  
(Please note: Fixing channel not supplied with the pinnable display boards)

7.



Add a header panel by inserting the header into the top frame and securing with the fixing channel

**Optional Extra:**



If you have purchased a spot light for your display board, simply attach to the frame in the desired position using the screw mechanism.