



USER
GUIDE




INFLATABLE SOFA



FUGU[®]'s advice :

**Inflate the furniture
to 30%. Then add the
customised cover and
inflate fully.**




FUGU® VALVE



1) Inflate the furniture at 60% with the **access to the air tank**. Then reajust the cover easily.

2) Close the **check valve** and finish inflation.



3) Screw the **cap**.



LIGHTING OPTION


1) Charge at **100%** before using the first time.

2) Insert a **LED lamp** inside the plastic pocket. Turn it on with the **remote control**.




INFLATABLE SOFA


1) See the location of the valve.




2) Lay down the sofa and its cover on the floor, inflate partially then.



3) Place the plastic bladder as the drawing below.




4) Put the cover string in the eyelets of the structure.




5) Tighten string and make a knot.




5) Finish covering the plastic bladder.




5) Place the cover properly.



6) Close the check valve and finish inflating.







7) Screw the cap.



REPAIRS

The fugu furniture has to be inflated for repairs. Holes bigger than 2cm cannot be repaired.

<p>IF THERE IS A HOLE</p> <p>1) Inflate the sofa.</p> 	<p>2) Take the glue and the plastic patch out of the plastic bag.</p> 	<p>3) Cut out a circle that is twice the size of the hole.</p> 	
<p>4) Carefully apply some glue on the hole.</p> 	<p>5) Immediately place the patch over the hole.</p> 	<p>6) Press the patch for a few minutes</p> 	<p>7) Remove all air bubbles and glue residue around the patch.</p> 



IMPORTANT

Do not use the Airflower for 48 hours after any repairs.